# 373-GFR Ground Fault Relay

The 373-GFR is designed to detect dangerous ground fault currents before damage is caused to expensive power assets. An undetected fault current may lead to cables overheating, which could start a fire. If high fault currents are involved, hazardous voltages may also appear on grounded equipment, putting lives at risk. The 373-GFR ground fault relay allows the fault current to be continuously monitored and compared with the user selectable trip level. Should the fault exceed this level, the relay will trip to indicate a fault condition. With a very fast response time of under 40ms, the supply can be disconnected before serious damage can occur. This product is intended to provide a high degree of ground fault protection and monitoring for any type of electrical equipment, specifically switchboards, generator sets and transformers.

#### Operation

The 373-GFR offers a single-pole change over relay contact incorporating a single set point, which will de-energise on trip. The relay senses the ground current by measuring the voltage developed across the N-G link impedance under a fault condition. We offer link selection of two standard N-G impedances, 0.2m ohms or 2m ohms. This is a very cost effective method, since a current transformer is not required.

The 373-GFR features two incremental rotary selector switches on the front panel and a series of LED annunciators. The 10 position trip current switch offers selectable ground fault current settings from 100 to 1200 amps and the 16 position time delay set point switch offers additional delay for fault discrimination, selectable from 0 to 10 seconds.

Once the trip current and time delay selections have been made, a green LED provides indication of mains healthy supply. The red LED will automatically illuminate if the pre-set fault level has been exceeded, (after any selected time delay). The unit also incorporates a bar graph of 5 yellow LEDs providing indication of the level of fault in 20% increments. When all 5 LEDs are illuminated the fault level has reached 100% of the set point setting.

The unit features a combined reset and test button. A short press of the button will reset the unit after a trip and one long press initiates an electronic confidence check. The relay latches on to a fault until the test/reset button is pressed or the auxiliary power is removed. However, automatic reset can be achieved by fitting a wire between two terminals. The relay will de-energise on trip (fail safe) as standard.

## **Analogue Outputs**

The 373-GFR unit incorporates an O/ImA analogue output which equals 0% to 100% of the selected tripping level. It can be used to drive an external test meter or panel meter, thus providing measurements for test commissioning and a useful indication of potential problems. The analogue output also enables fault level diagnosis to be communicated into building management or intelligent SCADA systems, whereby insulation deterioration can be monitored over a period of time and preventative maintenance arrangements made prior to expensive equipment failure.

## Product Codes - Single-pole change over relay

Frequency	Auxiliary supply	Cat. no.
50Hz	12-48V dc	373-GFRW-SHC5-A1-SP
50Hz	24-48V ac/dc	373-GFRW-SHC5-A2-SP
50Hz	100-250V ac/dc	373-GFRW-SHC5-A3-SP
60Hz	12-48V dc	373-GFRW-SHC6-A1-SP
60Hz	24-48V ac/dc	373-GFRW-SHC6-A2-SP
60Hz	100-250V ac/dc	373-GFRW-SHC6-A3-SP



#### Features

Precision digital settings LED bar graph display 10 selectable trip levels – 100 to 1200 amps 16 selectable time delay – 0ms to 10 seconds Less than 40ms response time 0-1mA analogue output User selectable input range of 0.2m ohms or 2m ohms User selectable latching/self-resetting Single-pole change over relay 8 amp 250V rated relay contacts


## Benefits


DIN-rail 43880 enclosure Switched mode supply accepts a wide range of auxiliary voltages Isolation of faulty circuits Insulation monitoring Advanced warning of faults Protection of expensive power assets Current transformer not required

## Applications

Switchgear Distribution systems Generator sets Control panels Utility power monitoring Transformer protection

#### Dimensions






## DIN 43880

## Specifications

Measuring input	AC voltage developed across N-G link		
Measuring range	$0.2\Omega$ or $2\Omega$ shunt impedance link selectable		
Overload	Maximum input voltage 600V		
Frequency	50/60Hz		
Auxiliary voltage	12 - 48V dc, 24 - 48V ac and dc or 100 - 250V ac and dc		
Auxiliary burden	Less than 1.5 Watts		
Trip current settings	Selectable 100A, 150A, 200A, 250A, 300A, 450A, 600A, 750A, 800A, 1200A		
Trip accuracy	50% <trip <math="" current="" point="">\leq100% in accordance with IEC 1543</trip>		
Trip response time	<40ms (at 5 x rated trip current, ignoring the selected time delay)		
Time delay set points	Selectable Oms, 50ms, 100ms, 150ms, 200ms, 300ms, 400ms, 500ms, 600ms, 700ms, 800ms, 900ms. 1 second, 2 seconds, 5 seconds, 10 seconds.		
Indication	5 yellow LED bar graph for fault levels Red LED indicated trip function Green LED indicated auxiliary power presence		
Relay contacts	1-pole change over (SPCO or NO+NC) contacts		
Relay contact rating	8 amps at 250V ac 8 amps at 30V dc resistive		
Relay mechanical life	>100,000 operations		
Analogue output	0 to 1 mA = 0 to 100% of selected tripping level. Compliance 1V, accuracy 10%		
Enclosure style	DIN 43880, rail width 70mm		
Material	Flame retardant UL94V0		
Terminals	1 to 4mm <sup>2</sup> solid or stranded conductors. IP20 protection		
Operating temperature	-10°C to +60°C		
Storage temperature	-20°C to +70°C		
Relative humidity	<95% non condensing		
Weight	<250g		
Dimensions	71mm wide x 90.5mm high x 73mm deep 2.79" wide x 3.56" high x 2.87" deep		

#### Connections

Install the neutral to ground shunt resistor in a suitable location. Connect the shunt sense wires directly to terminals N (neutral side) and G (ground side) on the relay. Cabling between the shunt resistor and the ground fault relay should be kept to a minimum.



#### Terminal No.

Terminal No.				
8	Neutral input			
6	Ground input			
2	Fused auxiliary supply (-)			
1	Fused auxiliary supply (+)			
4	Default operation is			
	non-latching			
5	Fit link to enable relay			
	latch on trip			
9/10	Analogue output 0/1mA			
11	Default input range is for			
	2mff shunt			
12	Link to select 200Qff			

- shunt input
- 14 Relay (NO)15 Relay (COM)
- 16 Relay (NC)



#### Features

Leakage measurement range 0-10 amps 6 models available Integral wire sealable terminal cover Flame retardant high impact moulded case

#### Benefits

Reduction of high currents for ease of metering Wide operating temperature -10°C to +50°C Steel mounting feet supplied Long product life

## **Applications**

Switchgear Distribution systems Generator sets Control panels Motor protection Transformer protection Overload protection

## Approvals

IEC 60044-1

## CBT-94F Core Balanced Current Transformers

The CBT-94F series of core balanced current transformers are exclusively for use with our 373-ELR earth leakage protection relay. The extremely sensitive toroidal core and secondary winding are encapsulated by a self extinguishing case providing excellent mechanical strength, protection from damage and electrical insulation.

## Description

Residual current devices are used to detect potentially dangerous earth fault currents before damage is caused. An undetected fault current may lead to cables overheating, which could start a fire. If high fault currents are involved, hazardous voltages may also appear on earthed equipment, putting lives at risk. An earth leakage protection relay is intended to provide a high degree of protection and monitoring for any electrical equipment, specifically motors and their control gear, generator sets and transformers. The leakage current is determined by passing the phase conductors (and neutral if present) through a core balanced current transformer.

## Operation

Primary conductors should be grouped together and fed through the current transformer aperture. It is essential that each conductor passes through the device in the same direction. Each phase conductor (and neutral if present) must pass through the current transformer. The current transformers sum the currents flowing into and back from the load. Ideally, the load will have no leakage current, so current flow through the CT will completely cancel out. For example, 100 amps flowing into load and 97 amps flowing back provides an output of 3 amps.

The equipment grounding conductor must always bypass the current transformer. The connections between the current transformer and protector should be kept as short as possible to minimise signal noise. For best results, use screened cable with the screen grounded at the protector.

## Specification

System voltage	720V maximum
Test voltage	3kV ac for 1 minute
System frequency	50Hz or 60Hz
Primary ratings	From 30mA to 10A
Secondary terminals	Protected to IP20
Operating temperature	-10°C to +50°C
Enclosure	UL94VO flame retardant plastic
Compliant with	IEC 60044-1, VDE 0414
Mounting hardware	Steel mounting feet for wall or base mounting

## **Product Codes**

Aperture Dim E	Dim A	Dim B	Dim C	Dim D	Cat no.
35mm	100mm	79mm	26mm	48.5mm	CBT-94F-035
70mm	130mm	110mm	32mm	66mm	CBT-94F-070
105mm	170mm	146mm	38mm	94mm	CBT-94F-105
140mm	220mm	196mm	49mm	123mm	CBT-94F-140
210mm	299mm	284mm	69mm	161mm	CBT-94F-210
300mm	400mm	380mm	-	-	CBT-94F-300

